


Guide – EC2 Security Group settings to open port 80

Web Application Development COP3834

Professor Navarro

LAMP stack should be installed by this point. This is step is necessary to send http request to apache web server.

- Step 1: Open AWS Management Console for instance
- Step 2: From AWS Management Console, Select Security Groups
- Step 3: Create Security group button on left



Step 4: Create rules as follows and press Create Security Group at bottom right

Edit inbound rules Info							
nbound rules control the incoming traffic that's allowed to reach the instance.							
Inbound rules Info							
Security group rule ID	Type Info	Protocol Info	Port range Info	Source Info		Description - optional Info	
sgr-0049fef43c33018ad	HTTP ▼	TCP	80	Custom ▼	Q	all ip http traffic	Delete
					0.0.0.0/0 🗙		
sgr-04e337f2c13bb182d	HTTPS ▼	TCP	443	Custom ▼	Q	secure https traffic	Delete
					0.0.0.0/0 ×		
Add rule							

Set inbound and outbound rules for EC2. Specifically for port 80 inbound.

Amazon tutorial can also be found at

https://docs.aws.amazon.com/AmazonRDS/latest/UserGuide/CHAP_Tutorials.WebServerDB.CreateVPC.html#CHAP_Tutorials.WebServerDB.CreateVPC.SecurityGroupEC2


Step 5: Check status of apache with systematl status httpd to ensure active

```
ec2-user@ip-172-31-14-199 ~]$ systemctl status httpd
 httpd.service - The Apache HTTP Server
Loaded: loaded (/usr/lib/systemd/system/httpd.service; disabled; vendor preset: disabled)
  Drop-In: /usr/lib/systemd/system/httpd.service.d
            └php-fpm.conf
   Active: active (running) since Thu 2021-08-12 23:20:41 UTC; 1min 0s ago
     Docs: man:httpd.service(8)
 Main PID: 15823 (httpd)
   Status: "Total requests: 0; Idle/Busy workers 100/0; Requests/sec: 0; Bytes served/sec: 0 B/sec"
   CGroup: /system.slice/httpd.service
             -15823 /usr/sbin/httpd -DFOREGROUND
            —15829 /usr/sbin/httpd -DFOREGROUND
—15830 /usr/sbin/httpd -DFOREGROUND
             -15831 /usr/sbin/httpd -DFOREGROUND
             -15832 /usr/sbin/httpd -DFOREGROUND
            L15833 /usr/sbin/httpd -DFOREGROUND
Aug 12 23:20:41 ip-172-31-14-199.us-east-2.compute.internal systemd[1]: Starting The Apache HTTP Server...
Aug 12 23:20:41 ip-172-31-14-199.us-east-2.compute.internal systemd[1]: Started The Apache HTTP Server.
[ec2-user@ip-172-31-14-199 ~]$ _
```

Step 6: Create an index.html file to test. Place in /var/www/html directory

Step 7: Test http request to your public URL. (Use your public web address)


http:// http://ec2-3-144-2-004.us-east-2.compute.amazonaws.com/



Step 8: Disable apache when finished testing

[ec2-user@ip-172-31-14-199 ~]\$ sudo service httpd stop
Redirecting to /bin/systemctl stop httpd.service
[ec2-user@ip-172-31-14-199 ~]\$

Step 9: Review Security Group settings



Step 10: Go back and review security settings and httpd status if index.html not accessible Complete